


## EG ADAPTERS

Adapters for connecting the ignition advance variator wiring plug to the crankshaft position sensor inductive connector without cutting the original sensor wiring.

Owing to the non-invasive connection to the signal from the crankshaft sensor in the event of possible problems, they allow a quick reconstruction of the original connection.

Designed for inductive sensors with 2-pin and 3-pin connectors



## TECHNICAL DATA

- Code WS004020102 (2-pin plug).  
Used in EG DYNAMIC, OSCAR55 DYNAMIC, EG SUPERIOR48.4.
- Code WS004020203 (3-pin plug).  
Used in EG DYNAMIC, OSCAR55 DYNAMIC, EG SUPERIOR48.4.
- Code WS003030101 (3-pin plug).  
Used in EG DYNAMIC, OSCAR55 DYNAMIC, EG SUPERIOR48.4.

